
# **YP-BBK** Installation Instructions

## **General Warnings & Notations:**

- 1. All Yak-Power plug and play accessories are specifically designed to work together while maintaining the correct battery polarity throughout the entire Yak-Power system. Use of other aftermarket connectors or splicing other connectors into the Yak-Power system may cause damage to the system or to the accessories connected to the system and void your warranty.
- 2. CAUTION: Always pay attention to the actual wire colors of all Yak-Power accessory cables to insure that the RED (+) wire is always connecting to the RED (+) wire on the connector into which it is being plugged.

The Power Pack comes with an integrated Power Port outlet making it easy to plug in and power your 12v accessories. The built in Master Power Switch, gives you full control of when your power is ON or OFF. The compact waterproof design of the Power Pack will hold up to 3 7AH batteries or 2 12AH batteries while still being small enough to stow away in many hatches. And, the integrated, external DUAL USB charging port will insure that both your mobile device and outdoor action camera have all the power they need to capture all of the action while you're out on the water. The Power Pack also comes with a 1000 MAH home smart trickle battery charger that will maintain your batteries and insure you always have a full charge every time you go out. (Batteries not included)

Works with Power Ports (YP-PMC48S, YP-PMC96S, or YP-PMC144S), Power Panel switching system (YP-RP5R), and Power Plug (YP-SAE4)



(switch must be in the on position

for batteries to charge)

DO NOT EXCEED the 15 AMP FUSE RATING

When attaching wires to batteries make sure the red wires are attached to the pos. terminals and black wires to the neg. terminals. Unused wires can be taped off.

Batteries can be secured in the battery box using the adjustable mounting brackets and strap.

### Connecting the battery charger

When charging batteries plug charger into the power port and turn on switch. Blue LED will be lit on usb charger whether switch is on or not.

#### Southern Audio Services, Inc. 14763 Florida Blvd., Baton Rouge, La 70819 225-272-7135 or 800-843-8823 www.yak-power.com www.southernaudioservices.com Rev. 4/10/2017


# **YP-BBK** Installation Instructions

## **General Warnings & Notations:**

- 1. All Yak-Power plug and play accessories are specifically designed to work together while maintaining the correct battery polarity throughout the entire Yak-Power system. Use of other aftermarket connectors or splicing other connectors into the Yak-Power system may cause damage to the system or to the accessories connected to the system and void your warranty.
- 2. CAUTION: Always pay attention to the actual wire colors of all Yak-Power accessory cables to insure that the RED (+) wire is always connecting to the RED (+) wire on the connector into which it is being plugged.

The Power Pack comes with an integrated Power Port outlet making it easy to plug in and power your 12v accessories. The built in Master Power Switch, gives you full control of when your power is ON or OFF. The compact waterproof design of the Power Pack will hold up to 3 7AH batteries or 2 12AH batteries while still being small enough to stow away in many hatches. And, the integrated, external DUAL USB charging port will insure that both your mobile device and outdoor action camera have all the power they need to capture all of the action while you're out on the water. The Power Pack also comes with a 1000 MAH home smart trickle battery charger that will maintain your batteries and insure you always have a full charge every time you go out. (Batteries not included)

Works with Power Ports (YP-PMC48S, YP-PMC96S, or YP-PMC144S), Power Panel switching system (YP-RP5R), and Power Plug (YP-SAE4)



Southern Audio Services, Inc. 14763 Florida Blvd., Baton Rouge, La 70819 225-272-7135 or 800-843-8823 www.yak-power.com www.southernaudioservices.com

DO NOT EXCEED the 15 AMP FUSE RATING

When attaching wires to batteries make sure the red wires are attached to the pos. terminals and black wires to the neg. terminals. Unused wires can be taped off.

Batteries can be secured in the battery box using the adjustable mounting brackets and strap.

### **Connecting the battery charger**

When charging batteries plug charger into the power port and turn on switch. Blue LED will be lit on usb charger whether switch is on or not.