




Supplemental Mounting Options

POWER RAIL


Installation Instructions



2. Remove all mounting hardware from the end of the Power Rail arms. Place 6mm x 40mm bolt (1) through arm mounting hole. Add two 3mm spacers (2) between arm and mounting plate. Hand tighten 6 mm nylon locking nut (3). Place Power Rail center of the ATV rack.



Screw 4 bolts (4) with washers into threaded mounting plates (5). Rotate bolts and mounting plates until bolts are against rack tubing. Then tighten all 4 bolts evenly. You will have a 1/8 inch gap between spacers (2) and mounting arm after mounting plate is tightened against the atv rack tubing.



Tighten 6mm x 40mm bolt (1) until gap is gone and rail is tight. There will be a slight bend of the Power Rail Mounting arms.